



ORN SERIES







OR-001
6A. 1 WAY SWITCH
SAFARI




OR-002
6A. 2 WAY SWITCH
SAFARI




OR-003
6A. BELL PUSH SWITCH
SAFARI




OR-004
6A. 1 WAY SWITCH
SUPER




OR-005
6A. TWO WAY SWITCH
SUPER



OR-006
6A BELL PUSH SWITCH
SUPER




OR-011
INDICATOR LAMP




OR-012
2 PIN SOCKET



OR-013
2 IN 1 SOCKET




OR-021
MINI T. V. SOCKET




OR-022
MINI 2 LINE TELE JACK



OR-023
10 A KIT KAT FUSE



OR-024
16 A KIT KAT FUSE



OR-025
ELECTRONIC BUZZER



OR-031
MINI DIMMER




OR-032
MEDIUM DIMMER




OR-033
4 STEP FAN REGULATOR



OR-034
5 STEP FAN RAGULATOR



OR-041
16A. SAFARI 1 WAY SWITCH




OR-042
16A. SAFARI 2 WAY SWITCH




OR-043

16A. SAFARI 1 WAY SWITCH WITH JUNCTION BOX



OR-044

16A. SUPER 1 WAY SWITCH




OR-045

16A. SUPER 2 WAY SWITCH



OR-046

16A. SUPER 1 WAY SWITCH WITH JUNCTION BOX




OR-047

6A/16A. UNIVERSAL SOCKET



OR-048

6A/16A. UNIVERSAL SOCKET WITH JUNCTION BOX




OR-051

10A./ 20A. SAFARI S. S. COMBINED




OR-052

10A/20A. SAFARI S.S. COMBINE (WITH BOX)



OR-053

10A./ 20A. SUPER S. S. COMBINED



OR-054

10A/20A. SUPER S.S. COMBINE (WITH BOX)




OR-061

10A./ 20A. SAFARI 5 IN 1



OR-062

10A/ 20A. SAFARI 5 IN 1 (WITH BOX)




OR-063

10A./ 20A. SUPER 5 IN 1



OR-064

10A/ 20A. SUPER 5 IN 1 (WITH BOX)



OR-073

25A. D.P. SWITCH WITH INDICATOR



OR-071

SURFACE 32A. D. P. SWITCH WITH FLUSH & INDICATOR



OR-072

32A. FLUSH TYPE D. P. SWITCH

